

How to Install ArtWool

Install ArtWool insulation in just 3 easy steps:

- 1. Insert**
- 2. Compress**
- 3. Release**

ArtWool insulation **cuts quickly and accurately** with a knife for a **fitting around pipes, electrical boxes, wiring, ductwork, and between structural members.**

To do the work:

Wear long sleeved, **loose fitting clothing, gloves, eye protection, knee pads** and a **dust mask**. Tools needed:

- Tape measure
- Long serrated bread knife
- Straight edge
- Staple gun (When acoustical and or vapor barrier/retarder is required)
- Caulking gun/Acoustical sealant
- Acoustical and or vapor barrier/retarder if required